


## Migrating Your Data from Drobo to Drobo FS

To move your data from another model to Drobo FS, connect both computers simultaneously and copy the files you'd like to share.



Moving your data from any model Drobo to a Drobo FS:

1. Connect Drobo FS to your network and ensure it has sufficient free capacity to accommodate the additional data from your Drobo.
2. Copy ALL files from Drobo to Drobo FS.
3. Verify ALL files are in place and fully accessible on Drobo FS.
4. If you would then like to add the drives from the Drobo to the Drobo FS, remove the drives from Drobo and place them one at a time in the free data bays in Drobo FS.

**Note that this will ERASE ALL DATA on these drives.** This step cannot be undone. If you aren't sure that you've successfully copied all data onto Drobo FS, **do not complete this step.**